



Extra Night Light

Included in the box:

- 1 Extra Night Light
- 2 12V power adaptors



Safety precautions / Important information

- Always follow the laws and legislations that apply in your country.
- Do not leave plastic packaging near children to avoid risk of suffocation.
- Do not place the power adaptor outside, close to water or on heat sensitive materials.

LUDA Elektronik AB resigns all responsibility that might occur from abuse or incorrect usage of the products.

Installation

1. Check that no part is broken or damaged. Place the light in the ceiling above the center of the area you wish to light up.
2. Connect the power adaptor to the light and then to a 220V socket.

Warranty

The warranty is due, if no other terms agreed, 12 months from the date the product is purchased from the authorised LUDA Elektronik AB dealer. During the warranty time LUDA Elektronik AB is obliged to repair, alternately, replace the broken product with a similar product or a product with better functions. When LUDA Elektronik AB replaces the product, the new product will be covered by the original warranty during the remaining warranty time. If your product is replaced, previously used, completely functioning parts may be used. Replaced parts are owned and controlled by LUDA Elektronik AB.

The warranty does not cover damage that have arisen due to physical damage, accidents, natural disasters, the usage of incorrect power adaptors or usage of the products in deviant behaviours from what is recommended by LUDA Elektronik AB and in this user guide.

The end consumer will be responsible for all shipping costs that occur from transportation to the LUDA Elektronik AB repair shop. The warranty will only be valid if the original receipt, issued by the authorised LUDA dealer, can be presented. The original receipt needs to contain information regarding place of purchase, issue date and product description. LUDA Elektronik AB reserve the right to refuse to perform the warranty service if above mentioned receipt information has been removed, changed or is missing

Information regarding recycling

The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that all electrical and electronic products and accumulators must be taken to separate collection at the end of their working life. This requirement applies in the European Union. Do not dispose of these products as unsorted municipal waste.

Always return your used electronic products and packaging materials to a dedicated collection point. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. More detailed information is available from the product retailer, local waste authorities or your national producer responsibility organization.



Contact us

For more information and support, visit: www.ludaelektronik.com

E-mail: service@ludaelektronik.com

Telephone: +44 (0)20 30143799

Address: LUDA Elektronik AB, Aschebergsgatan 46, SE41133 Göteborg, Sweden